

# Micromax<sup>TM</sup> BQ242

#### **Electronic Inks and Pastes**

### **Carbon Conductive Composition**

Micromax<sup>TM</sup> BQ242 is a polymer thick film (PTF) carbon ink designed for carbon working electrodes in amperometic biosensors. It is suitable for biosensor manufacture by screen-printing on polyester film substrates.

#### **Product benefits**

- High electrochemical activity suitable for uses with a variety of electron-transfer mediators.
- · High conductivity
- Excellent adhesion to polyester film
- · Superior carbon electrode wettability
- · Halogen-free polymeric binder
- · Good ink rheology for screen printing

#### **Product information**

Solvent or thinner	Micromax <sup>™</sup> 8240
Density	1.23 g/cm <sup>3</sup>
Solid content	40.9 - 42.9 <sup>[1]</sup> %
[1]: 150°C	

#### Rheological properties

Viscosity	30 - 70 <sup>[2]</sup> Pa.s
[2]: Brookfield HBT, #14 spindle, 10 rpm, 25°C	

### Application technique

Mask mesh	180 - 280
Drying time	5 - 15 <sup>[3]</sup> min
Drying temperature	130 <sup>[3]</sup> °C
Theoretical coverage	250 - 280 <sup>[4]</sup> cm <sup>2</sup> /g
Recommended film thickness, dried	12.7 <sup>[5]</sup> - 20.3 <sup>[6]</sup> μm
101.1	

[3]: box oven[4]: at 12.7μm[5]: 280 mesh screen[6]: 180 mesh screen

#### Typical mechanical properties

Adhesion, cross hatch 5B class

Printed: 2023-09-21 Page: 1 of 3

Revised: 2023-06-26 Source: Celanese Materials Database



# Micromax<sup>TM</sup> BQ242

# Electronic Inks and Pastes

#### Electrical properties

Surface resistivity 18000 - 25000<sup>[7]</sup> mOhm per square

[7]: at 12.7µm thickness

# Storage and stability

Shelf life 6<sup>[8]</sup> months

[8]: in unopened containers, from date of shipment, at temperature <25°C (>0°C)

#### Additional information

How to use

## **Processing**

- Printing
  - Micromax<sup>TM</sup> BQ242 should be mixed throughly with a plastic or stainless steel spatula before use. Typical printing thickness: 0.8mil on 180 mesh screen, 0.5mil on 280 mesh screen.
- Clean-up solvent
  - Ethylene glycol diacetate or other glycol methyl either acetate.
- Drying
  - Allow drying times of 2-5 minutes for well-ventilated ovens or conveyor dryers at 130°C. For box oven drying, allow 5-15 minutes at 130°C.

### **Properties**

 Information in this datasheet shows anticipated typical physical properties for Micromax<sup>TM</sup> BQ242 based on specific controlled experiments in our labs and are not intended to represent the product specifications, details of which are available upon request.

#### Storage and shelf life

Micromax<sup>TM</sup> BQ Sreies compositions should be stored in a clean, stable environment at room temperature (~25°C) with their lids tightly sealed. Storage in high temperature (>30°C) or in freezers (<0°C) is NOT recommended as this could cause irreversible changes in the material. The shelf life of compositions in factory-sealed (unopened) containers stored under room temperature (~25°C) conditions is 6 months from the date of shipment. Some setting of solids may occer over time, so composition should be stirred thoroughly before use.

Printed: 2023-09-21 Page: 2 of 3

Revised: 2023-06-26 Source: Celanese Materials Database



# Micromax™ BQ242

# **Electronic Inks and Pastes**

# Safety and handling

For safety and handling information pertaining to this product, read Safety Data Sheet (SDS).

Printed: 2023-09-21 Page: 3 of 3

Revised: 2023-06-26 Source: Celanese Materials Database

NOTICE TO USERS: Values shown are based on testing of laboratory test specimens and represent data that fall within the standard range of properties for natural material. These values alone do not represent a sufficient basis for any part design and are not intended for use in establishing maximum, minimum, or ranges of values for specification purposes. Colourants or other additives may cause significant variations in data values. Properties of moulded parts can be influenced by a wide variety of factors including, but not limited to, material selection, additives, part design, processing conditions and environmental exposure. Other than those products expressly identified as medical grade (including by MT® product designation or otherwise), Celanese's products are not intended for use in medical or dental implants. Regardless of any such product designation, any determination of the suitability of a particular material and part design for any use contemplated by the users and the manner of such use is the sole responsibility of the users, who must assure themselves that the material as subsequently processed meets the needs of their particular product or use. To the best of our knowledge, the information contained in this publication is accurate; however, we do not assume any liability whatsoever for the accuracy and completeness of such information. The information contained in this publication should not be construed as a promise or guarantee of specific properties of our products. It is the sole responsibility of the users to investigate whether any existing patents are infringed by the use of the materials mentioned in this publication. Moreover, there is a need to reduce human exposure to many materials to the lowest practical limits in view of possible adverse effects. To the extent that any hazards may have been mentioned in this publication, we neither suggest nor guarantee that such hazards are the only ones that exist. We recommend that persons intending to rely on any recommendation or to use any e

© 2023 Celanese or its affiliates. All rights reserved. Celanese®, registered C-ball design and all other trademarks identified herein with ®, TM, SM, unless otherwise noted, are trademarks of Celanese or its affiliates. Fortron is a registered trademark of Fortron Industries LLC. KEPITAL is a registered trademark of Korea Engineering Plastics Company, Ltd.