ZEON CORPORATION

SPECIALTY PLASTICS DIVISION

1-6-2 Marunouchi, Chiyoda-ku TOKYO, 100-8246 JAPAN

Phone: +81-3-3216-1769 FAX: +81-3-3216-2334

Report No. B1013EV2

Injection Blow molding condition of ZEONOR® 1020R

1. Typical Molding Condition

• Mold / Tool 100ml bottle 6 cavity mold

• Molding Machine 3 Station Injection Stretching Blow Molding Machine

SB 3-250 Aoki Technical Laboratory, Inc

• Screw diameter 54mm

• Molding Condition

Nozzle	280 °C	536 °F	
Zone 1 (Front)	280 °C	536 °F	
Zone 2 (Middle)	278 °C	532 °F	
Zone 3 (Rear)	275 °C	527 °F	
Throat (under Hopper)	Water coolin	ng, N2 purge	
	260 ~ 280 °C 500 ~ 536 °F		
Injection mold (Core side)	90 °C	194 °F	
Injection mold Cavity side	95 °C	203 °F	
Blow mold	90 °C	194 °F	
Injection time		10 seconds	
Cooling time		12 seconds	
Blowing time		14 seconds	
	37 seconds		
	1.1 times		
	Zone 1 (Front) Zone 2 (Middle) Zone 3 (Rear) Throat (under Hopper) Injection mold (Core side) Injection mold Cavity side	Zone 1 (Front) 280 °C Zone 2 (Middle) 278 °C Zone 3 (Rear) 275 °C Throat (under Hopper) Water coolin 260 ~ 280 °C Injection mold (Core side) 90 °C Injection mold Cavity side 95 °C Blow mold 90 °C 10 second 12 second 14 second 37	

2. Preparation

- Predrying; Air (Oxygen) dissolved in ZEONOR pellets can cause discoloration, carbide and void, ZEONOR should be dried (heated) to remove air in the pellets for 4 to 12 hours at 70°C to 80°C (158°F to 176°F) before molding. Drying too long period may cause heat deterioration and possibly discoloration in the molded articles.
- Nitrogen purge; Nitrogen purge is recommended in barrel throat while molding to avoid oxidative degradation!!!

Please refer to ZEONOR Injection Molding Guide for more details.

The test results herein are believed to be accurate but are laboratory tests based on limited sampling, which do not necessarily simulate actual use conditions. NO REPRESENTATIONS, GUARANTEES OR WARRANTIES OF ANY KIND ARE MADE AND ZEON SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTY OF MERCHANTABILITY AND THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE. ZEON shall not be liable for and the customer assumes all risk and liability for any use or handling of any material beyond ZEON's direct control.