

DuPont™ Nucler® 960

Nucler® resins Product Data Sheet

Description

Product Description

Nucler® 960 is a copolymer of ethylene and methacrylic acid, made with nominally 15 wt% methacrylic acid. It is inherently flexible without the need for plasticizers. The resin can be pigmented, UV-stabilized for exterior applications and painted or plated for special decorative effects.

Restrictions

Material Status

- Commercial: Active

Typical Characteristics

Composition

15% By Weight Methacrylic Acid

Typical Properties

Physical	Nominal Values	Test Method(s)	
Density ()	0.94 g/cm ³	ASTM D792	ISO 1183
Melt Flow Rate (190°C/2.16kg)	60 g/10 min	ASTM D1238	ISO 1133
Thermal	Nominal Values	Test Method(s)	
Melting Point (DSC)	91°C (196°F)	ASTM D3418	ISO 3146
Freezing Point (DSC)	73°C (163°F)	ASTM D3418	
Vicat Softening Point ()	62°C (144°F)	ASTM D1525	ISO 306

Processing Information

General

Maximum Processing Temperature 235°C (455°F)

General Processing Information Nucler® 960 is readily processed in conventional extrusion equipment. Melt temperature may be varied over the range of 135-235°C (275-455°F).

Materials of construction used in the processing of this resin should be corrosion resistant. Stainless steels of the types 316, 15-5PH, and 17-4PH are excellent, as is quality chrome or nickel plating, and in particular duplex chrome plating. Type 410 stainless steel is satisfactory, but needs to be tempered at a minimum temperature of 600°C (1112°F) to avoid hydrogen-assisted stress corrosion cracking. Alloy steels such as 4140 are borderline in performance. Carbon steels are not satisfactory. While stainless steels can provide adequate corrosion protection, in some cases severe purging difficulties have been encountered. Nickel plating has been satisfactory, but experiments have shown that chrome surfaces have the least adhesion to acid based polymers. In recent years, the quality of chrome plating has been deteriorating due to environmental pressures, and the corrosion protection has not always been adequate. Chrome over top of stainless steel seems to provide the best combination for corrosion protection and ease of

purging.

If surface properties of the extruded resin require modification (such as, lower C.o.F. for packaging machine processing), refer to the Conpol™ Processing Additive Resins product information guide.

After processing Nucrel, purge the material out using a polyethylene resin, preferably with a lower melt flow rate than the Nucrel resin in use. The "Disco Purge Method" is suggested as the preferred purging method, as this method usually results in a more effective purging process. Information on the Disco Purge Method can be obtained via your DuPont Sales Representative.

Never shut down the extrusion system with Nucrel in the extruder and die. Properly purge out the Nucrel with a polyethylene, and shut down the line with polyethylene or polypropylene in the system.

FDA Status Information

Nucrel® 960 resin conforms to the U.S. Code of Federal Regulations, Title 21, paragraph 177.1330, covering their use as a food contact surface subject to the extractives limitations on the finished food contact articles as described in the regulation.

Safety & Handling

Nucrel® methacrylic acid copolymer resins as supplied by DuPont are not considered hazardous materials. As with any hot material, care should be taken to protect the hands and other exposed parts of the body when handling molten polymer. At recommended processing temperatures, small amounts of fumes may evolve from the resins. When resins are overheated, more extensive decomposition may occur. Adequate ventilation should be provided to remove fumes from the work area. Disposal of scrap presents no special problems and can be by landfill or incineration in a properly operated incinerator. Disposal should comply with local, state, and federal regulations. Resin pellets can be a slipping hazard. Loose pellets should be swept up promptly to prevent falls. For more detailed information on the safe handling and disposal of DuPont resins, a Material Safety Data Sheet can be obtained from the DuPont Packaging and Industrial Polymers website or by contacting your sales representative.

Read and Understand the Material Safety Data Sheet (MSDS) before using this product

DuPont Offices Worldwide

Americas

DuPont Company
Barley Mill Plaza 26-2363
Lancaster Pike & Route 141
Wilmington, DE 19880-0026 U.S.A.
Telephone +1 302-774-1161
Toll-free (USA) 800-628-6208 prompt "6"
Fax +1 302-999-4399

DuPont do Brasil, S.A.
Alameda Itapecuru, 506
06454-080 Barueri, SP Brasil
Toll-free: 0800 171715
Telephone +55 11 4166 8122
Fax +55 11 4166 8720

Asia Pacific

DuPont China Holding Co, Ltd.
15th Floor, Shui on Plaza
333 Huai Hai Road (Central)
Shanghai 200021, China
Telephone +86 21 6386 6366
Fax +86-21-6386-6333

DuPont K.K./DuPont Asia Pacific
Sanno Park Tower
11-1, Magatacho 2-chome
Chiyoda-ku, Tokyo, 100-611, Japan
Telephone +81-3-5521-2771
Fax +81-3-5521-2775

Europe / Middle East Africa

DuPont de Nemours Int'l.
S.A. 2,
Chemin du Pavillon Box 50
CH-1218 Le Grand Saconnex
Geneva, Switzerland
Telephone +41 22 717 51 11
Fax +41 22 717 55 00

nucrel.dupont.com
email: pip@dupont.com

Copyright © 2007 DuPont. All rights reserved. The technical data herein are guides to the use of DuPont resins. The advice contained herein is based upon tests and information believed to be reliable, but users should not rely upon it absolutely for specific applications because performance properties will vary from lot to lot and with processing conditions. It is given and accepted at user's risk and confirmation of its validity and suitability in particular cases should be obtained independently. The DuPont Company makes no guarantees of results and assumes no obligations or liability in connection with its advice.

This publication is not to be taken as a license to operate under, or recommendation to infringe, any patents. CAUTION: Do not use in medical applications involving permanent implantation in the human body. For other medical applications, see DuPont Medical Caution Statement, H-50102.

The DuPont Oval, DuPont™, The miracles of science™, and Nucrel® are trademarks or registered trademarks of DuPont or its affiliates.

Copyright© 1995-2007. E.I. duPont de Nemours and Company. All Rights Reserved.

This data sheet is effective as of 05/15/2007 02:07:51 PM and supersedes all previous versions.



The miracles of science™