

Technical Data Sheet

DuraStar™ Polymer MN611 Natural

Applications

- Blood contact and dialysis
- Fluid administration
- Medical devices
- Medical labware

Key Attributes

- Chemical resistance to most medical solvents including lipids and IPA
- Ease of processing
- Gamma and E-beam color stability

Product Description

DuraStar™ Polymer MN611 has been tested for FDA/ISO 10993 and USP Class VI Biological Evaluation testing after Gamma and EtO sterilization. It contains a mold release to improve ejection. It has excellent appearance and is nearly water-clear. Benefits include toughness, chemical resistance, and excellent processing characteristics. MN611 has very good toughness.

Typical Properties

Property ^a	Test Method ^b	Typical Value, Units ^c
General Properties		
Specific Gravity	D 792	1.2
Mold Shrinkage Parallel to Flow, 3.2-mm (0.125- in.) thickness	D 955	0.002-0.006 mm/mm (0.002-0.006 in./in.)
Mechanical Properties (ISO Method)		
Tensile Strength @ Yield	ISO 527	47 MPa
Tensile Strength @ Break	ISO 527	46 MPa
Elongation @ Yield	ISO 527	4 %
Elongation @ Break	ISO 527	200 %
Tensile Modulus	ISO 527	1800 MPa
Flexural Modulus	ISO 178	1850 MPa
Flexural Strength	ISO 178	65 MPa
Izod Impact Strength, Notched @ 23°C	ISO 180	7.8 kJ/m ²
@ -40°C	ISO 180	4.8 kJ/m ²
Mechanical Properties		
Tensile Stress @ Yield	D 638	47 MPa (6900 psi)
Tensile Stress @ Break	D 638	51 MPa (7400 psi)
Elongation @ Yield	D 638	5 %
Elongation @ Break	D 638	300 %
Flexural Modulus	D 790	2000 MPa (2.9 x 10 ⁵ psi)
Flexural Yield Strength	D 790	69 MPa (10000 psi)
Rockwell Hardness, R Scale	D 785	103
Izod Impact Strength, Notched @ 23°C (73°F)	D 256	80 J/m (1.5 ft·lbf/in.)
@ -40°C (-40°F)	D 256	40 J/m (0.7 ft·lbf/in.)
Impact Strength, Unnotched @ 23°C (73°F)	D 4812	NB
@ -40°C (-40°F)	D 4812	NB
Impact Resistance (Puncture), Energy @ Max. Load		42 J (31 ft·lbf)

@ 23°C (73°F)	D 3763	
@ -40°C (-40°F)	D 3763	48 J (35 ft·lbf)
Optical Properties		
Haze	D 1003	0.3 %
Regular Transmittance	D 1003	89 %
Total Transmittance	D 1003	91 %
Thermal Properties		
Deflection Temperature		
@ 0.455 MPa (66 psi)	D 648	74 °C (165 °F)
@ 1.82 MPa (264 psi)	D 648	65 °C (149 °F)
Typical Processing Conditions		
Drying Temperature		71 °C (160 °F)
Drying Time		3-4 hrs
Processing Melt Temperature		232-277 °C (450-530 °F)
Mold Temperature		16-38 °C (60-100 °F)

^aUnless noted otherwise, all tests are run at 23°C (73°F) and 50% relative humidity.

^bUnless noted otherwise, the test method is ASTM.

^cUnits are in SI or US customary units.

Eastman Medical Disclaimer

It is the responsibility of the medical device manufacturer ("Manufacturer") to determine the suitability of all component parts and raw materials, including any Eastman product, used in its final product in order to ensure safety and compliance with requirements of the United States Food and Drug Administration (FDA) or other international regulatory agencies.

Eastman Chemical Company products have not been designed for nor are they promoted for end uses that would be categorized by either the United States FDA or by the International Standards Organization (ISO) as implant devices. Eastman products are not intended for use in the following applications: (1) in any bodily implant applications for greater than 30 days, based on FDA-Modified ISO-10993, Part 1 "Biological Evaluation of Medical Devices" tests (including any cosmetic, reconstructive or reproductive implant applications); (2) in any cardiac prosthetic device application, regardless of the length of time involved, including, without limitation, pacemaker leads and devices, artificial hearts, heart valves, intra-aortic balloons and control systems, and ventricular bypass assisted devices, or (3) as any critical component in any medical device that supports or sustains human life.

Eastman Chemical Company products offered for the medical market have met selected FDA-Modified ISO-10993, Part 1 "Biological Evaluation of Medical Devices" tests with human tissue contact time of 30 days or less. The tests include: cytotoxicity, sensitization, irritation or intracutaneous reactivity, systemic toxicity (acute), subchronic toxicity (sub-acute), implantation, hemocompatibility. The Manufacturer is responsible for the biological evaluation of the finished medical device.

The suitability of an Eastman Product in a given end-use environment is dependent upon various conditions including, without limitation, chemical compatibility, temperature, part design, sterilization method, residual stresses, and external loads. It is the responsibility of the Manufacturer to evaluate its final product under actual end-use requirements and to adequately advise and warn purchasers and users thereof.

Comments

Properties reported here are typical of average lots. Eastman makes no representation that the material in any particular shipment will conform exactly to the values given.

Eastman and its marketing affiliates shall not be responsible for the use of this information, or of any product, method, or apparatus mentioned, and you must make your own determination of its suitability and completeness for your own use, for the protection of the environment, and for the health and safety of your employees and purchasers of your products. No warranty is made of the merchantability of fitness of any product, and nothing herein waives any of the Seller's conditions of sale.