



ALTECH PA6 IQ 2030/W100 GF30

(Last update: 27.03.2025)

MCOM

Base Polymer Polyamide 6
Filler/Additive System 30 % glass fibres

Colour black

Special Features processing stabilised, contains recycled material, Industrial quality

Market Segment Automotive

Typical Applications injection moulded parts

Pre-Drying Conditions 80 °C in a dry air (dessiccant) dryer

for 2-12 h

dependant on moisture content max. moisture content <0,15 %

Processing Injection Moulding melt temperature 270-290 °C

mould temperature 80-100 °C

Storage dry, protected from light

Properties	dry/cond.	Dimension	Test Norm
Mechanical Properties			
Flexural Modulus	5700 / -	MPa	ISO 178
Flexural Strength	137 / -	MPa	ISO 178
Tensile Modulus	7000 / -	MPa	ISO 527
Tensile Strength at Break	110 / -	MPa	ISO 527
Tensile Elongation at Break	5 / -	%	ISO 527
Impact Strength (Charpy, 23°C)	60 / -	kJ/m²	ISO 179/1eU
Impact Strength (Charpy, -30°C)	41 / -	kJ/m²	ISO 179/1eU
Notched Impact Strength (Charpy, 23°C)	6 / -	kJ/m²	ISO 179/1eA
Notched Impact Strength (Charpy, -30°C)	4 / -	kJ/m²	ISO 179/1eA
Rheological Properties			
Melt Index (MVR)	60 / *	cm ³ /10min	ISO 1133
MVR temperature	275 / *	°C	-
MVR load	5 / *	kg	-
Physical Properties			
Density	1360 / -	kg/m³	ISO 1183
Ecological Properties			
Global Warming Potential (GWP)	0.66	kg CO ₂ eq./kg	ISO 14040, 14044

Additional Information

Altech® IQ (IQ = industrial quality) is based on changing post-industrial and post-consumer raw materials. This results in fluctuating properties and processing conditions. The specification range of Altech® IQ is therefore very limited and cannot be extended. When using raw materials from a recycling process, as with prime materials, ferrous / non-ferrous residues can never be completely ruled out. In order to reduce the risk of possible effects of such residues to a minimum, MOCOM uses extensive detection and separation systems in the

ALBIS Distribution GmbH & Co. KG Phone: + 49 (0) 40 78105-0 TDS11689 Print Date: 2025-07-16 05:19:49

Technical Data Sheet





ALTECH PA6 IQ 2030/W100 GF30

(Last update: 27.03.2025)

MCOM

production process of Altech® IQ compounds. However, even these quality assurance systems cannot guarantee that the resulting product is 100% free of such residues. We therefore recommend that our customers also use their own detection and separation systems adapted to their particular process. This is particularly important with regard to applications using hot runner technology. For further questions and specific information in connection with Altech® IQ grades, please contact our application engineering department. The ecological properties listed in this document were calculated for a production in one of our European plants. Data for production in the United States or China can be provided by sending a request to the following address. technical@mocom.eu

Liability Exclusion

These are guide values and not a specification. The test values mentioned are representative values only and not binding minimum or maximum figures. These test values have been determined on standardised test specimens and can be affected by pigmentation, mould design and processing conditions.

Any information given on the chemical and physical characteristics of our products, including, without limitation, technical advice on applications, whether verbally, in writing or by testing the product, is given to the best of our knowledge and in good faith and does not exempt the buyer from carrying out their own investigations and tests in order to ascertain the product's specific suitability for the purpose intended.

The buyer is solely responsible for confirming the suitability of the product for a particular application, its utilization and processing and must observe any applicable laws and government regulations. NO EXPRESS OR IMPLIED RECOMMENDATION OR WARRANTY IS GIVEN WITH REGARD TO THE SUITABILITY OF THE PRODUCT FOR A PARTICULAR APPLICATION, SUCH AS, BUT NOT LIMITED TO, SAFETY-CRITICAL COMPONENTS OR SYSTEMS.

Healthcare uses: the supply of any product by ALBIS for any medical, pharmaceutical or diagnostic application is conditional to an assessment by ALBIS in terms of compliance with ALBIS' internal risk management policy – even for products which are in general designated for use in Healthcare applications.

Important: irrespective of product type or designation, ALBIS does not recommend or support the use of any products it supplies which fall into the following medical, pharmaceutical or diagnostic application categories:

Phone: + 49 (0) 40 78105-0

Print Date: 2025-07-16 05:19:49

- risk class III applications according to EU directive 93/42/EEC
- any bodily implant application for greater than 30 days
- any critical component in any medical device that supports or sustains human life.

At all times, our standard terms and conditions of sale apply.